




REBOTEC® Rehabilitationsmittel GmbH

PO Box Q541 Queen Victoria Building **NSW 1230**



rebotec.com.au info@rebotec.com.au

User Instructions

Rollator Polo-Plus-T

S
181.10
Serial Number

M
181.20
Serial Number

L
181.30
Serial Number

User Weight: max. 120 kg





Important advisories!

- Read this User Instructions before first-time use of the Rollator and keep it ready for the user.
 - Adhere to all advisories, especially the safety advisories.
- Keep this User Instructions booklet at hand for future use and subsequent sales.
- The user instructions and the maintenance manual are downloadable on our homepage.



Product Description



Rollator diagram shows:

Nonator diagram shows.		
Front wheel bow		
Rear wheel bow		
Grip frame / handgrip		
Front wheel compl. / swivel castor		
Rear wheel / brake wheel		
Hand lever		
Brake handle		
Plastic seat, foldable		
Star grip for adjusting handle height		
red pull-cord		
Brake lever with brake pad		
Cable for brake		
Bag attached with Velcro		
Nameplate for product		

Nameplate (Z) - Example



Always observe the allowable maximum patient body weight!

The name-plate is very important for product identification, and thus must not be removed..

Table of contents

1.	General advisories	3
1.1	Introduction	3
1.2	Intended proper use	3 3
1.3	Equipment advisories	3
	Managar	
2.	Warranty	3
3.	Spare parts orders, complaints	3
4.	Re-use, lifetime	3
	I a.	
5.	Disposal	3
6.	Symbol advisory	3
0.	Symbol advisory	
7.	Safety advisories for use	4
	,	
8.	Scope of delivers	4
9.	Spare parts	4
10.	Setting up for use	5
	Coming up for ucc	
11.	Using the Rollator	5
11.1	Getting the Rollator ready for use	5
11.2	Sitting down and standing up	5
11.3	Pushing the Rollator	6
11.4	Hand brakes	6
	Locking and rolling brakes	
11.5	Folding the Rollator	6
11.6	Adjusting the brakes	6
40	Transfer de la companya de la compan	
12.	Troubleshooting	6
13.	Care	6
	1 00.0	
14.	Maintenance	7
15.	Technical specifications / equipm.	7
16	Acceptony	0
16.	Accessory	8



We recommend, if possible, keeping the packaging for later transport. This will allow secure packaging in the event of a return transport.





1. General advisories

1.1 Introduction

In this User Instructions booklet, you will find information and advisories for set-up, use, operation, maintenance and care of the Rollator Polo-Plus-T.

1.2 Intended proper use

The Rollator is an aid for patient mobility and is to be used by patients who have limited balance capability and considerably impaired ability to walk. The grip bow is height-adjustable to match the user's size.

The Rollator **must not** be used by patients who have disorders with perception, extremely limited balance capability, loss of or limited use of joints in both arms and who have difficulties sitting down.

The Rollator can be used inside and outside and may be used only on solid, even surfaces. Never transport heavy objects with the Rollator.



1.3 Equipment advisories

The Rollator consists of a powder-paint coated frame and a height-adjustable grip bow. The 4 wheels consist of four tyres and plain bearings. The front wheels may be swivelled 360 degrees and the rear wheels are fixed.

A plastic seat serves for sitting (resting) and can be folded as a tablet. Hand brake levers with braking function are mounted on the grip handle on both the right and left sides. By activating the brake lever, the permanent locking or rolling brake can be activated.

The grip bow is completely rubber-coated in the area of the hand-grips. The Rollator is foldable for allowing easy transport. A pouch is attached to the frame. At the front of the frame is a removable bag attached with Velcro.

2. Warranty

There is a **2-year warranty** on our Polo-Plus-T Rollator. A prerequisite for the warranty is use in accordance to the requirements outlined herein, as well as conducting regular maintenance. Excluded are all wear parts (e.g.: brake pads, brake cable, wheel, hand lever, seat board, bag).

Not observing the User Instructions, improper maintenance and unauthorised modifications done to the product without the manufacturer's permission automatically lead to the immediate nullification of warranty and product liability (see Maintenance).

The delivery date written on the REBOTECdelivery note applies as the valid start date of the warranty period.

3. Spare parts orders, complaints

To exclude incorrect spare parts deliveries and to ensure rapid processing of complaints, always provide the product name, serial number (SN) and the product's year of manufacture. You can find this information on the Rollator's nameplate or on the front cover of this User Instructions booklet.

4. Re-use, lifetime



The re-use (lifetime) depends on the product's condition. Before re-use, maintenance of the Rollator must be conducted and the applicable instructions concerning safety care and maintenance must be fully adhered to.

The expected lifetime of the Rollator can be **up to 3 years** when used properly and the safety instructions, maintenance intervals and care instructions are followed.

Beyond this time period, the Rollator can be used further if it is still in a safe condition (after a complete inspection).

5. Disposal

The Rollator consists of aluminium tubing, metal, and plastic which are all recyclable. Products that can no longer be used are to be disposed of separately from regular household rubbish. This must be done according to the local and national regulations for environmental protection and raw material recycling. Please contact your local disposal company or officials for further information.

6. Symbol advisories

Symbol - nameplate:



Read the User Instructions!

Product conforms to the Medical Products Directive 93/42/EEC



Year of Manuf. Product



Serial No. Product

Symbols in the User Instructions:



Important advisory or information!



Language



Caution – Follow safety advisories!



Care





7. Safety advisories for use

A Rollator is a technical aid, and the user must abide by the following safety advisories and rules:



Danger of falling!

- Before each use, check for the proper function of the brakes and the overall stability of the Rollator.
- Be sure that the brakes are first set at the permanent locking position before using the Rollator. Release the brakes first only when you are secure on your feet.
- Before starting to walk, check the locking mechanism for unintended folding of the frame.
- First begin by walking and push the Rollator while standing upright with both hands gripping the grip handles
- Check to be sure that the star-handles on the grip bow are tightened.
- Always walk inside of the Rollator and do not push the Rollator too far in front of you in order to avoid incorrect loading and increased risk of falling down.
- Sitting down and standing up by a patient must be monitored according to the health condition of the patient, and if necessary, must be assisted by a trained care-worker.
- Use of the Rollator by users who do not have complete physical control and normal movement must not be done unsupervised.
- Push the Rollator according to your physical capability. If feeling tired while walking, then stop and rest on the seat. Sitting on the seat must be done only when the brakes are in the permanently locked position!



Danger of slipping!

- Do not attempt to grab the grip handles with wet hands as you may lose your grip and slip.
- When sitting down on the seat, do not sit only on the front edge. Sit on the entire seat. Before sitting down, set the brakes in the permanently locked position!



Danger of tipping over!

- When using the Rollator outside, use it only on even, solid paths and avoid high curbs and steps. If possible, look for areas with low curbs or have someone assist you in overcoming obstacles.
- Avoid using the Rollator on cobblestone surfaces or similar irregular surfaces. Avoid paths with steep grades, both going up or down, as you may lose control of the moving Rollator.
- Do not use the Rollator on any steps or stairs.

 Do not hang any objects on the Rollator and do not bend too far forwards over the grip bow as there is a danger of tipping over.



Caution! Danger of breakage!

- The Rollator is not a transportation device for heavy objects. Adhere to the maximum allowable user body weight (see the nameplate on the Rollator).
- Don't stand on the Rollator or use it for transporting persons.



Danger of pinching!

 There is an increased risk of pinching limbs and fingers at all joints and hinges on the Rollator. Be extra careful of possible pinching of body parts or objects when folding and unfolding the Rollator.



Danger of injury!

 At surface temperatures over 40°C (104°F), there's a risk of injury. Therefore do not expose the Rollator to any source of heat (exposure to the sun, storing near a heater, cleaning with hot water) just before the Rollator is used. Before using the Rollator, allow it to cool down.

8. Scope of delivery

The product has been carefully inspected in the factory for freedom of defects and for completeness. After having received it, carefully check over the product for possible transport damages and for completeness.

- 1 Rollator with bag
- 1 User Instructions

9. Spare parts

Article No.	Name, description
288.00.45	Front wheel, black, D=200 mm
288.00.46	Rear wheel-black, D=200 mm
280.00.60	Brake cable*
280.10.52	Brake pad**
280.10.25	Seat-screw design 09
284.00.20	Bag for model "S"
284.00.60	Bag for model "M" and "L"
02.05.098	User Instructions
02.11.149	Maintenance Instructions

^{*} Brake cable length must be matched to the grip frame.

^{**} Always replace the brake pads in pairs.



10. Setting up for use

The product is delivered partially pre-assembled in the carton. The following assembly instructions must be carried out before first-time use:

Set-up and adjustment must be done by an authorised dealer!

 The Rollator is delivered folded up for transport reasons. Place the Rollator on its wheels and push the wheels apart by pressing the rear wheel frame downwards.




2. Check to be sure the Rollator is completely unfolded and that the folding lock is secured. Be sure the pouch is securely mounted.





3. The height of the grip handles must match the user's height. Loosen both star grip screws (A) and pull them out. Adjust the grip handles (B) to the desired height. Line up the holes and then tighten together with the star screws.



- 4. Check to be sure the hand-brakes function properly (see: 11.4).
- 5. Check to be sure that the brake cables are not kinked or damaged.
- Check to be sure that the seat easily folds over and back.

11. Using the Rollator

When using the Rollator the following points must be adhered to:

Before use, it must be assured that the Rollator is in a proper condition for safe use.

If defects or malfunctions are detected, then the Rollator must not be used. In this case the defect or malfunction must be removed by a qualified serviceman.

11.1 Getting the Rollator ready for use

The Rollator must be unfolded and the locking pins must click into position. Check to be sure that the brake units are in good condition and functioning properly (see: 11.4).

11.2 Sitting down and standing up

Before sitting down on the seat and standing up, it must be assured that the Rollator is secured against rolling away or tipping over. Activate the brakes on both sides.

Sitting down

Stand as closely as possible to the seat. While supporting yourself on the grip frame, sit down slowly on the seat.

Be sure that you sit down on the entire seat and not just on the edge in order to avoid slipping away.

Standing up

Before standing up, be sure that both feet are firmly on the floor.

With both arms placed on the grip frame, get up carefully from the seat.

Do not lean too far forward in order to avoid falling down.

If sitting down and getting up are not possible alone, then have someone assist you.

11.3 Pushing the Rollator

- While walking, support yourself up front in the area of the grip-frame.
- Always walk in the interior area of the Rollator and do not push it too far in front of you. You can expand the inner area by folding the seat over.
- Do not bend over too far beyond the grip frame.
- When using the Rollator outside, use it only on solid even surfaces and paths. Avoid high curbs, if possible.
- When using the Rollator inside, do not roll it against door sills and thresholds, and watch out for loose or slippery floor coverings.
- While walking, do not have the permanent locking brake engaged or continuously apply the brakes. When pushing the Rollator, both brakes must be disengaged.



11.4 Hand brakes



The improper use of brakes can lead to unsafe situations and damage (increased wear, functional limitations).


The Rollator must not be rolled when the brakes are applied or when the wheels are blocked by the permanent brakes.

Permanent locking brakes (H)

Push both brake levers downwards until they click into position. Both rear wheels are now braked. To disengage the brakes, pull the brake levers back up.

Rolling brakes (G)

By pulling both (left and right) brake levers upwards, both rear wheels are braked. When releasing the levers, the brakes are then disengaged and the rear wheels are free to roll.




11.5 Folding the Rollator

Unfolding

Place the Rollator down on its wheels and press the frame downwards. The folding lock mechanism (locking pins) must click fully into position.

Folding up


Flip the seat over and pull the **red pull-cord** with one hand until the locking mechanism is released. Using the other hand, lift the tube frame towards you.



11.7 Adjusting and tightening the brakes

If the braking effect diminishes over time, then the Rollator may not be used and it must be repaired or adjusted by a qualified serviceman. It is decided whether an adjustment is enough, or if parts need to be replaced, by conducting a visual inspection.

Loosen lock nut (X) and then adjust the brake with the adjustment screw (Y). Be sure that the released brake allows the wheel to turn unhindered, and that the wheel is locked when the brake is pulled. Then re-tighten the lock nut.



12. Trouble-shooting

Fault	Possible cause	Correction
Wheels turn with difficulty	Gummed up	Clean, inspect regularly
Locking pins jam	Gummed up	Clean, Replace locking pins
No brake function	Faulty	Maintenance! Replace item
Reduced brake function	Generally defective, wear	Maintenance, Adjust brake
Wheels are bent	Impact against obstacles	Maintenance! Replace
Visible cracks or breakage	Various causes	Maintenance! Replace

13. Care



In general the Rollator can be cleaned using a mild conventional cleaning and disinfecting agent. Then simply wipe the Rollator with clean water and cloth, and then wipe dry with a clean cloth.

Do not use an abrasive scouring agent or cleaner (read the product instructions!) that contain aggressive solvents (acids, thinners, etc.). Do not use stiff cleaning brushes, as these will damage the plastic surfaces or cause deposits to build up on the plastic parts and other materials.



14. Maintenance

The cause of accidents or damage may be due to the late detection of wear and / or improper use, as well as irregular maintenance.



For safety reasons and for preventing accidents, the Rollator must undergo a complete maintenance at least once a year. (Refer to the Medical Products Act and local requirements).

Special requirements of the product arising from use by the patient may require more frequent maintenance intervals.

Maintenance / scope of inspection

Maintenance should include the following checks and be documented:

Annex: Maintenance Report and Maintenance Overview.

- Visual check of all frame parts, such as: (damage, wear and corrosion)
 - Rollator frame
 - Grip handles
 - Swivel castors
 - Brake wheels
 - Brake cable sets
 - Hand levers with brake lever
 - Plastic seat
 - Back pad see: accessory
- ➤ Check all connector elements (screws, nuts) for completeness. Check fit and function.
- > Check function of the folding mechanism.
- > Function of the height adjustment.
- Function the brakes.
 - Braking when rolling (rolling braking).
 - Locking of the brakes (permanent locking)



If you have questions concerning maintenance and repairs to the Rollator, then contact an authorised dealer or medical equipment supply outlet.

When making repairs, use only original spare parts from REBOTEC. Observe all advisories concerning guarantee and warranty.

Never make any unauthorised modifications or conversions to the Rollator. These will only adversely affect the safety and function of the Rollator.

In such cases REBOTEC overtakes no liability!

Follow all the instructions when ordering spare parts, re-use and product lifetime of the Rollator. After a complete maintenance or repair of the Rollator is done, we recommend a complete cleaning for assuring hygiene. Follow the cleaning instructions.

15. Technical specifications / equipment

Advisory!

We reserve the right to make modifications and further developments with regards to the illustrated design and specifications contained in this User Instructions booklet at any time without the notice.

Specifications	Polo-Plus-T/S	
Max. user weight	120	kg
Product weight	7.4	kg
Max. additional weight	4.0 / bag content	kg
Length approx.	700	mm
Width approx.	670	mm
Seat width	480	mm
Seat height approx.	490	mm
Grip height approx. 5 stages / hole adjustm. approx. 20mm / hole)	640 to 740	mm
Turning radius approx.	950	mm
Plain bearing wheels	D=200	mm
Space needed (LxBxH)	670x670x520	mm
Specifications	Polo-Plus-T/M	
Max. user weight	120	kg
Product weight	7,6	kg
Max. additional weight	4.0 / bag content	kg
Length approx.	700	mm
Width approx.	670	mm
Seat width	480	mm
Seat height approx.	550	mm
Grip height approx. 7 stages / hole adjustm. approx. 20mm / hole)	690 to 820	mm
Turning radius approx.	950	mm
Space needed (LxBxH)	750x670x520	mm
Plain bearing wheels	D=200	mm
Specifications	Polo-Plus-T/L	
Max. user weight	120	kg
Product weight	7.8	kg
Max. additional weight	4.0 / bag content	kg
Length approx.	700	mm
Width approx.	670	mm
Seat width	480	mm
Seat height approx.	600	mm
Grip height approx. 10 stages / hole adjustm. approx. 20mm / hole)	740 to 920	mm
Turning radius approx.	950	mm
Space needed (LxBxH)	840x670x520	mm
Plain bearing wheels	D=200	mm

For all models:

Angle between longitudinal centre line of handgrip and movement direction: 0 degrees (parallel))

Type of brake 2x permanent brakes

process tolerance: +/-15 mm





16. Accessory

Back pad/0,210 kg (Art. No.: 280.10.48) Suitable for models "M and "L"



For shopping a removable bag with zipper is offered. It's placed into the included bag fixed at the walker.

(Loading weight max. 4 kg)








Attention! Always put the shopping bag into the included bag fixed at the walker and do not attach it to the handle bar or put on the seat. Otherwise, there's an increased danger of tipping over.

Back pad/0, 0060 kg (Art. No.: 280.10.48) Suitable for all models

For a more comfortable sitting (back support) a back cushion is offered. Fastening takes place using a zipper (A) on the handle bracket.



We also supply

Walking aids

Shoulder crutches

Shower stools

Shower and commode chairs

Multifunction-Wheel Chairs Rollators

Patient lifting hoists Standing up aids

Your REBOTEC Team